



Replacing display

1. From the Home screen select Shut down to turn off the machine
2. Unplug the power cord
3. Disconnect cables and replace the display (refer to illustration)
4. Reconnect the cables
5. Plug in the power cord and turn on the machine

Calibrating touchscreen

1. From the Home screen, go to Settings > Personal > Touchscreen
2. Select Calibrate
3. Using Stylus touch each target + on the screen
4. Select OK to save settings
5. Select Done to go back to the Home screen